

1.000.000



TESTED AND APPROVED BY
1.000.000 SUCCESSFUL HUNTERS

Hand Cocking System

The BAR Zenith Wood HC possesses a longer piped barrel that offers a more accurate line of sight. The new manual cocking system located on the top of the pistol grip offers an extra degree of safety.

BAR Zenith Wood Hand Cocking



The manual cocking system lets you literally cock your rifle, by moving the arming plunger forwards, which puts the hammer springs under load.

Your gun is now ready to fire.



When hunting and at your firing station, you can feed a cartridge into the chamber of your

gun and then use the manual cocking system for putting the cocking plunger in the "uncocked" position. Your rifle is now safe. When you want to fire, you just have to push the plunger forwards. Your rifle is now ready and all that you still need to do is to squeeze the trigger.



You can just as easily uncock your gun by pressing on the cocking pushbutton on the

top of the plunger. This removes the load from the hammer springs and makes your gun inoffensive, and therefore safe.

It is a very simple easy-to-use system that gives your rifle an extra degree of safety.



1 Cocking plunger in the "uncocked" or safety position.

2 Cocking plunger in the "cocked" position, a red dot appears. Your gun is ready for firing.

3 Uncock your BAR Zenith by pressing the pushbutton downwards.